

TECHNICAL INFORMATION SHEET

LIMESCALE REMOVER

Product Description

Limescale Remover is an acidic cleaner for the removal of limescale from kitchen equipment, utensils and dishwashing machines.

Features and Benefits

- Fast effective removal of limescale.
- Concentrated blend of inorganic acids and non-ionic surfactants.
- Suitable for removing hard water scales and other inorganic deposits from dishwashers, bain maries, vending machines and other water using equipment.

Use Instructions

Descaling

1. Add solution to the article to be cleaned, for best results heat the solution to 50°C.
 2. Leave to soak until all scale has been removed.
 3. Rinse out thoroughly with clean water.
 4. To ensure no product residue remains a further second rinse is recommended.
- CAUTION: Contains hydrochloric acid, use with caution on hydrochloric acid sensitive surfaces - may discolour stainless steel. If unsure pre-test surfaces prior to use. If a less aggressive product is required Tap & Shower Head Descaler may be used.

Scale Level	Concentration
Heavy Scaling	Use Neat
Light Scaling	Dilute with up to 4 parts water

Dishwashing machine descaling

1. Switch off dosing equipment.
2. Fill dishwasher with fresh water.
3. Add 200ml of Limescale Remover to the water.
4. Circulate the solution for 10-15 minutes.
5. Drain and inspect for complete limescale removal.
6. Repeat if required.
7. Fill dishwasher with fresh water and circulate with water only for 10 – 15 minutes.
8. Allow to dry leaving door open.
9. Switch on dosing equipment.

Safe Handling and Storage

See visual information to the right.

Full guidance on the handling and safe use of the product can be obtained from the Safety Data Sheet.

Store in original container.

Avoid extremes of temperature.

Health & Safety

HAZARD AS SUPPLIED



Causes severe skin burns and eye damage.



HAZARD WHEN USED
AT RECOMMENDED
DILUTION.



Causes severe skin burns and eye damage.



Technical Information

Appearance: Red liquid

pH : < 1

Relative density: 1.09

Odour: Characteristic

Solubility: Fully miscible in water

The above data is typical of normal production and should not be taken as a specification.

Materials Compatibility

Do not use on acid-sensitive surfaces, e.g. enamel, marble, grouting or tiles.

Immediately remove any drops or splashes from acid-sensitive surfaces and rinse thoroughly with water. Do not mix with bleach or other cleaning products. Test material compatibility in a small, inconspicuous place before use.